Induction Cooktop, 24", 4 Zones with SmartZone

Contemporary



Pair your four cooking zones to create two large SmartZones with the energy efficiency and responsiveness of induction.

- Immediate heat response and extremely accurate temperature control
- Child and pet safe – cooktop remains cool to touch until a pot or pan is placed on the surface
- PowerBoost activates a very high heat, bringing liquid to boil in less than a minute
- Touch&Slide controls easily control each cook zone

DIMENSIONS

Height	**3 11/16 "**
Width	**23 5/8 "**
Depth	**20 7/8 "**



SPECIFICATIONS

Burner ratings

Maximum burner power	**Yes**

Cleaning

Flat easy clean glass surface	•

Controls

Auto cut-off timer for each zone	•
Minute timer	•
Soft-touch electronic controls	•
Touch and slide controls	•

Performance

Auto heat reduce	•
Dual colour display	•
Dual zones	•
Heat settings	**9**
Induction cooking technology	•
Zone bridging	•

Power requirements

Amperage	**30 A**
Supply frequency	**60 Hz**
Supply voltage	**208 - 240 V**

Product dimensions

Depth	**20 7/8 "**
Height	**3 11/16 "**
Width	**23 5/8 "**

Safety

Individual hot surface indicators	•
Keylock	•
Pan detection system	•

Safety time out	•
Spillage auto off	•
Surface hot indicators	•

Zone ratings

Left front	**2100W**
Left front zone (PowerBoost set)	**3700W**
Left rear	**2100W**
Left rear zone (PowerBoost set)	**3700W**
PowerBoost	**up to 3700W**
Right front	**2100W**
Right front zone (PowerBoost set)	**3700W**
Right rear	**2100W**
Right rear zone (PowerBoost set)	**3700W**

Zones

Number of zones	**4**

SKU	81368

The product dimensions and specifications in this page apply to the specific product and model. Under our policy of continuous improvement, these dimensions and specifications may change at any time. You should therefore check with Fisher & Paykel's Customer Care Centre to ensure this page correctly describes the model currently available. © Fisher & Paykel Appliances Ltd 2020

Other product downloads available at fisherpaykel.com

- DWG
- DXF
- Data Sheet (English)
- Installation Guide (English)
- Installation Guide (Canadian French)
- User Guide (English)
- User Guide (Canadian French)

Where applicable:

All appliances use energy, and energy usage typically generates carbon emissions. **Fisher & Paykel Appliances' In-use Energy Carbon Emissions Estimate** indicates carbon emissions from a product's in-use energy. This is calculated either annually or per cycle, using the product's market-specific energy label energy consumption data multiplied by the carbon emissions factor for energy in your country or region.

Our In-use Energy Carbon Emissions Estimate is designed to assist customers in making informed purchasing decisions when comparing different Fisher & Paykel products. For example, a heat pump dryer typically has a lower In-use Energy Carbon Emissions Estimate than a vented dryer.

24/7

A PEACE OF MIND SALE

24 Hours 7 Days a Week Customer Support

T 1.888.936.7872 **W**www.fisherpaykel.com