Freestanding Dishwasher, Sanitise

Contemporary




With flexible racking you can adjust to suit your load, and multiple wash features for beautifully clean dishes.

- Six wash programs, as well as additional Quick wash, Sanitise and Extra Dry options
- Auto option senses the optimum wash cycle for your dishes
- Full width utensil tray for quick access to cutlery

DIMENSIONS

Height	**870 mm**
Width	**597 mm**
Depth	**600 mm**



SPECIFICATIONS

Capacity and loading

Accommodates round plates up to	**300mm**
Adjustable height, foldable cupracks	•
Easy lift adjustable upper basket	•
Fold down tines	•
Full width cutlery/utensil tray	•
Height adjustable rear wine glass supports	•
Pitch adjustable tines	•
Wine glass supports	•

Consumption

Energy rating	**4 star**
Water rating	**5.5 star (WELS)**

Controls

End of cycle beeps	•
Energy saving delay start option of up to 12 hours	•
Keylock	•
Rinse aid indicator light	•
Time remaining LED display	•

Features

Half load option	•
Quiet operation	•
ThermoDry system	•
Three-stage filtration system	•
Variable wash pressure technology	•

Performance

Noise emissions	**43 dBA**

Power requirements

Amperage	**10A**
Supply frequency	**50Hz**
Supply voltage	**220 - 240V**

Product dimensions

Depth	**600 mm**
Height	**870 mm**
Width	**597 mm**

Wash Program Modifiers

Extra Dry	•
Half load	•
Quick	•
Sanitise	•

Wash Programs

Auto	•
Delicate	•
Eco	•
Fast	•
Heavy	•
Medium	•
Rinse	•

Water connection

Water pressure	**100kPa - 1000kPa**
Water supply	**3/4" BSP (20mm) Connector Water Inlet Hose**

SKU	81631

The product dimensions and specifications in this page apply to the specific product and model. Under our policy of continuous improvement, these dimensions and specifications may change at any time. You should therefore check with Fisher & Paykel's Customer Care Centre to ensure this page correctly describes the model currently available. © Fisher & Paykel Appliances Ltd 2020

Other product downloads available at fisherpaykel.com

- Installation Guide (English)
- Quick Start Guide (English)
- User Guide (English)

Where applicable:

All appliances use energy, and energy usage typically generates carbon emissions. **Fisher & Paykel Appliances' In-use Energy Carbon Emissions Estimate** indicates carbon emissions from a product's in-use energy. This is calculated either annually or per cycle, using the product's market-specific energy label energy consumption data multiplied by the carbon emissions factor for energy in your country or region.

Our In-use Energy Carbon Emissions Estimate is designed to assist customers in making informed purchasing decisions when comparing different Fisher & Paykel products. For example, a heat pump dryer typically has a lower In-use Energy Carbon Emissions Estimate than a vented dryer.

24/7

A PEACE OF MIND SALE

24 Hours 7 Days a Week Customer Support

T 0800 372 273 **W**www.fisherpaykel.com