Front Loader Washer Dryer Combo, 7kg + 4kg

Combination




A complete laundry solution for when you need to maximise space while washing and drying your clothes with superior fabric care.

- With 10 continuous wash and dry cycles including Delicate and Quick wash, 10 wash only cycles and 9 dry only cycles
- 7kg wash load and 4kg dry load
- Easy installation with no venting required
- Wash and dry an average load in under three hours

DIMENSIONS

Height	**850 mm**
Width	**600 mm**
Depth	**590 mm**



SPECIFICATIONS

Capacity

Capacity	**Wash (7kg), + Dry (4kg)**

Consumption

Energy rating	**A**
Water consumption per cycle	**51L**
Water usage (per dry cycle)	**26L**

Continuous Wash & Dry Cycles

Cottons	•
Everyday	•
Heavy	•
Quick Wash	•
Rinse	•
Spin	•
Synthetics	•
Towels	•

Features

Add a garment (immediate door opening)	•
Anti-fungal door gasket	•
Auto out of balance correction	•
Child/Keylock	•
Cold water inlet	•
Controlled cold	•
Delay start	•
Detergent dispenser	**Manual**
Fabric softener dispenser	**Manual**
Flood protection	•
Pre Wash	•
Rinse +	•
SmartTouch™ control dial	•
Stainless steel drum	•
Water temperature controls	**5**
Wrinkle Free	•

Performance

Auto-Lint disposal	•
Maximum spin speed	**1400 rpm**
Number of spin speeds	**5**
SmartDrive™ technology	•
Vortex wash	•

Product dimensions

Depth	**590 mm**
Height	**850 mm**
Width	**600 mm**

Wash Cycles

Allergy	•
Cottons	•
Customise cycle	•
Delicate	•
Everyday	•
Heavy	•
Quick 30	•
Rinse	•
Spin	•
Synthetics	•
Towels	•

SKU	98136

The product dimensions and specifications in this page apply to the specific product and model. Under our policy of continuous improvement, these dimensions and specifications may change at any time. You should therefore check with Fisher & Paykel's Customer Care Centre to ensure this page correctly describes the model currently available. © Fisher & Paykel Appliances Ltd 2020

Other product downloads available at fisherpaykel.com

- Energy Label
- Installation Guide - Cavity Sizes (English)
- Installation Guide (English)
- Installation & User Guide (English)

Where applicable:

All appliances use energy, and energy usage typically generates carbon emissions. **Fisher & Paykel Appliances' In-use Energy Carbon Emissions Estimate** indicates carbon emissions from a product's in-use energy. This is calculated either annually or per cycle, using the product's market-specific energy label energy consumption data multiplied by the carbon emissions factor for energy in your country or region.

Our In-use Energy Carbon Emissions Estimate is designed to assist customers in making informed purchasing decisions when comparing different Fisher & Paykel products. For example, a heat pump dryer typically has a lower In-use Energy Carbon Emissions Estimate than a vented dryer.

24/7

A PEACE OF MIND SALE

24 Hours 7 Days a Week Customer Support

T 1800 625174 **W**www.fisherpaykel.com